


Super - Spreader

* INSTRUCTIONS *



ADJUST SPREADER HEAD
TO ARC TUBE CENTRE

BY
← SLIDING →

ARC TUBE

LAMP

ADJUST TO
APPROX.
2 - 5mm

SQUEEZE ROUND-BRACKET
TOGETHER AND TIGHTEN
THUMB SCREW

BEND SO SPREADER IS
PARALELL WITH LAMP



www.super-spreader.com